
HOGGI[®]



BASIC home under frame
Spare parts catalogue

Spare parts

1 Modelidentification and basic equipment

1.1 Modelidentification	3
1.2 Basic equipment	3


3 Spare parts

3.1 Base frame	5
3.2 Column frame with baseplate	6
3.3 Seat retainer	7
3.4 Part's list , for seat retainer	8
3.5 Push bar	9
3.6 Twin wheels	10

Spare Parts

1.1 Modelidentification


Please give us the Serial number with every spare part order, to ensure a correct delivery.



1.2 Basic configuration


- Base frame with adjustable pillar.
- Seat retainer adapter for BINGO-Evolution for size: Mini, 1 or 2.
- Four twin whell`s with lock.

2 Component overview




Pos	Article number	Articel description	Page
1	3002-0000-032	Base frame	5
2	3002-1200-032	Column frame	6
3	300x-130x	Seat retainere	7
4	3002-5400	Push bar for BASIC	9
5+6	124x-000x	Twin wheel`s	10

Spare Parts



Pos	Article number	Articel description	Quantity	Unit
1	3002-1110-032	Base frame, black dull matt	1	Pc.
2	1141-0019	Ribbed insert 30x0,8-2,5	4	Pc.

Spare parts




Pos	Article number	Articel description	Quantity	Unit
1-7	3002-1200E-032	Column frame with baseplate, complete	1	Pc.
1	3002-1210-032	Column frame with baseplate, black dull matt	1	Pc.
2	3002-1230	Bushing spacer 10 x 0.8 x 26.8	4	Pc.
3	1029-0845	Button head socket screw M8x45	4	Pc.
4	1051-0008	Washer A8,4	4	Pc.
5	1042-0008	Hexagon nut self-locking M8	4	Pc.
6	3002-1220	ZUG clamping unit	1	Pc.
6.1	3002-1221	Clamp block front	1	Pc.
6.2	3002-1222	Clamp block back	1	Pc.
6.3	1012-1055	Hexagon head screw M10x55	1	Pc.
6.4	1051-0010	Washer A10,5	1	Pc.
6.5	1121-0010	Locking lever M10	1	Pc.
7	3002-1211-032	Baseplate	4	Pc.

Spare parts



Pos	Article number	Articel description	Quantity	Unit
1-24	3002-1303E-032	Seat retainer for Mini, complete	1	St
	3002-1302E-032	Seat retainer size 1, complete	1	St
	3003-1302E-032	Seat retainer size 2, complete	1	St
1	3002-1390-032	Seat retainer for Mini, black dull matt	1	St
	3002-1360-032	Seat retainer size 1, black dull matt	1	St
	3003-1360-032	Seat retainer size 2, black dull matt	1	St
2	1141-0009	Ribbed insert SFL 25x1-2,5	2	St
3	1089-0002	Wedge M8x21	2	St
4	3002-1323-016	Immersion tube chrome-plated	2	St
5	3002-1322	Saddle washer 25x802-1322	2	St
6	1024-0630	Hexagon socket countersunk head screw M6x30	4	St
7	1021-0885	Hexagon socket head cap screw M8x85	2	St
8	1052-0008	Spring washer B8	2	St
9	1051-0006	Washer A6,4	4	St
10	1044-0006	Hexagonal domed cap nut self-locking M6	4	St
11	3002-1372-006	Scantlings rails	2	St
12	3231-1516	Scantlings bearing	2	St
13	3231-1514	latch ramp	2	St
14	1113-0051	Washer PA 6,4x15x5	2	St
15	3002-1381-015	Seat bearing right	1	St
16	1134-0006	Snap button B 141	1	St
18	3002-1371E-015	Seat bearing left	1	St
19	3231-9523	Button	1	St
20	3002-1373-022	Side panel, left, signal white	1	St
21	3002-1383-022	Side panel, right, signal white	1	St
22	1051-0005	Washer A5,3	1	St
23	1044-0005	Hexagonal domed cap nut self-locking M5	1	St
24	1030-0510	Button head socket screw with flange M5x10	1	St

Spare Parts



Pos	Article number	Articel description	Quantity	Unit
1-11	3002-5400	Push bar for BASIC home under frame	1	Pc.
1	3002-5432-007	Clamp push handle, black anodized	1	Pc.
2	3002-5431-007	Push handle, black anodized	1	Pc.
3	1059-0011	Shim ring zp DIN/ISO 988 8x14x1,2	1	Pc.
4	1121-0830	Locking lever PA black M8x30	1	Pc.
5	1021-0620	Hexagon socket head cap screw M6x20	1	Pc.
6	1051-0006	Washer A6,4	1	Pc.
7	1042-0006	Hexagon nut self-locking M6	1	Pc.
8	1143-0001	Handle grip d30 x 260	1	Pc.
9	1141-0009	Ribbed insert SFL 25x1-2,5	2	Pc.
10	1134-0006	Snap button B 141	1	Pc.
11	3002-5433-032	Adapter plate push handle black dull matt	1	Pc.

Spare parts



Pos	Article number	Articel description	Quantity	Unit
1	1241-0001	Twin wheel castor, d=75 mm, with wheel lock, threaded pin M10x15	4	Pc.
2	1240-0002	Apparatus castor125 mm with total lock, incl. screw M10x30	4	Pc.

HOGGI GmbH
Eulerstraße 27 - 56235 Ransbach-Baumbach - Deutschland
(+49) 0 2623 / 92 499-0
www.hoggi.de